



www.theypod.net

877-932-7686

solutions@yearoundinnovations.com

The Ypod is not waterproof. If drainage holes are needed, simply drill the four corners of the legs as shown. (1/2" to 3/4" holes)



1. Drill drainage holes from 1/2" to 3/4" diameter, one in each corner of the bottom of the Ypod.

The Ypod, while providing a rugged and protective covering for all kinds of roll materials, does not provide a water-tight seal. If your Ypod will be exposed to rain or snow on a regular basis, either mounted on the jobsite, or stored in a pickup or other truck, please consider drilling drainage holes, as directed, in each of the bottom corners of the Ypod.