



www.theypod.net

877-932-7686

solutions@yearoundinnovations.com

Loading Instructions

The Ypod is designed for polyfilm, visqueen or other roll sheet materials measuring 20' wide by 100' long or roll products with a packaged length of 32" long by 12" in diameter or less. Following are instructions for loading a polyfilm roll into the Ypod.



1. Typical packaging of a 20' wide by 100' long roll of polyfilm or visqueen.



2. Stand box on its end. Make sure the end of the roll is flush and not telescoped.



www.theypod.net

877-932-7686

solutions@yearoundinnovations.com



3. Insert spindle through the center tube.



4. Lay box on its side, and cut open a corner of the box to expose the roll.



5. Lift roll by spindle ends and set into the Ypod's spindle supports.



6. Ypod ready for use.